

MODEL # BR-173-B**CUTTING CHART**

- Remove whip from bottom loading coil
- Measure from bottom of center phasing coil to bottom of whip - cut from bottom

FREQUENCY MHz	WHIP LENGTH MM	WHIP LENGTH INCHES
430	375	14 3/4
435	356	14
440	342	13 7/16
445	338	13 5/16
450	334	13 1/8

WHIP LENGTH WITH OPTIONAL # 1214 SPRING

FREQUENCY MHz	WHIP LENGTH MM	WHIP LENGTH INCHES
430	306	12 1/16
435	297	11 11/16
440	278	10 15/16
445	270	10 5/8
450	260	10 1/4

Use these NMO mounts for #BR-173-B antenna

With installed UHF PL-259 Male connector on
17 ft. low loss double shield RG-58A/U cable

Magnet - Black	Model # BR-317
Magnet - Chrome	Model # BR-316
Trunk Lip - Chrome	Model # BR-311
Surface - 3/4" Hole	Model # BR-1250

With installed Mini-UHF Male connector on
17 ft. low loss double shield RG-58A/U cable

Magnet - Black	Model # BR-317-MUHF
Magnet - Chrome	Model # BR-316-MUHF
Trunk Lip - Chrome	Model # BR-311-MUHF
Surface - 3/4" Hole	Model # BR-1251-MUHF

Tram-Browning, Inc.
PO Box 5056
Edmond, OK 73083 USA